



Mayer-Johnson

Introduces the Boardmaker® Activity Pad!

Simple and flexible, the Boardmaker Activity Pad puts interactive activities in the learner's hands!

- ★ Activities are recorded on the SmartPocket, not the Activity Pad, and can be used in any Boardmaker Activity Pad!
- ★ Freeform button layout—no preset grid!
- ★ At least 4 minutes total recording time per SmartPocket—use as needed for activities!
- ★ Create activities in Boardmaker, print photos, or tear a page out of a magazine! Any printed material can be used in a SmartPocket!
- ★ Up to 32 programmable buttons per activity and two activities per SmartPocket!
- ★ Get really creative . . . includes over 125 Boardmaker sample activities and templates to get you started!
- ★ Create switch accessible buttons—switch jacks are built in!



Actual size
11 1/2" x 9 1/2" x 1 1/4"
13.6 oz

US Pat 6,661,407

A natural extension to the Boardmaker family of software, the Boardmaker Activity Pad (BAP) moves interactive activities beyond the computer and brings them right to the learner. Using innovative patented technology, printed activities are inserted into SmartPockets that slide easily into the BAP, buttons are assigned and recorded, and everything is saved to a chip on the SmartPocket itself. Each pocket carries its own recording time! The SmartPockets can then be moved from BAP to BAP, carrying the activities with them.

An Unlimited Number of Interactive Activities

Two activities are held in each SmartPocket. Each activity can have up to 32 programmable buttons and draws from a minimum of four minutes of total recording time per SmartPocket. Activities are saved to the SmartPocket, not to the BAP, and SmartPockets can be re-recorded for new activities. Free form layouts allow buttons to be located almost anywhere, rather than conforming to a set button grid configuration. Activities are easily created in Boardmaker (sample activities and templates are included), and a unique print option prints both activities on a single letter-sized sheet of paper, inverting one activity, so that when folded both activities are positioned correctly in the SmartPocket. While Boardmaker is ideal for designing and printing activities, photographs or other printed material can be used in a SmartPocket.

Easy to Use

Activities slide easily and quickly into the durable vinyl SmartPockets. After the buttons for an activity are assigned and recorded, learners can use and enjoy the saved activities over and over again by quickly sliding them into and out of the BAP. Volume controls are easy to use, and a headset may be used for private learning. Buttons can be made switch-accessible with the built-in switch jacks. BAP control keys and the SmartPockets can be locked to prevent unwanted changes. These features, along with unlimited activity possibilities, provide learners at any grade level with access to the curriculum, and allow for differentiation and individualization at all levels from early childhood to high school.

Reinforce Learners' Strengths and Build Their Skills

A versatile teaching and multi-modal learning system, the BAP utilizes voice output, visual stimulation and tactile activation, and is designed to maximize student learning and facilitate many types of instruction and practice. The BAP is an ideal instructional tool for all students, and can provide initial instruction, extend classroom lessons and activities, or reinforce basic skills. Learners with cognitive challenges, processing difficulties, fine or gross motor concerns, speech therapy needs, and memory issues will especially benefit from the interactive learning experiences the BAP can provide.

Features

- 10 SmartPockets™ included!
- Removable, two-sided, portable durable vinyl SmartPocket
- Up to 32 programmable buttons per side of SmartPocket
- At least 4 minutes total recording time per SmartPocket
- Unlimited number of activities
- Over 125 Boardmaker sample activities and templates included
- Activities can be moved from BAP to BAP
- Removable SmartPocket guard snaps in to keep users from removing SmartPocket
- Built-in retractable carrying handle
- Turn photos or any printed material into an activity using the free form layout
- Volume control/headset options
- Dual speaker design provides plenty of volume
- Large LCD display makes BAP easy to configure
- Locking options
- Create switch accessible buttons—switch jacks are built in

Requires four AA batteries.

X0MJ190	Boardmaker Activity Pad	\$795
X0MJ192	Boardmaker Activity Pad and Boardmaker Win CD	\$995
X0MJ191	Boardmaker Activity Pad and Boardmaker Mac* CD	\$995
	Cont. US shipping \$15	

*Boardmaker for Mac does not currently have the Boardmaker Activity Pad print option. Activities must be printed on letter size paper and cut apart before inserting into a SmartPocket.



Additional SmartPocket™ packs, carrying options, key guards and other accessories also available!

**Call (800) 588-4548
or visit www.mayer-johnson.com**